

SHELTA Extra Large Resin Wheeled Base – Correct Installation of Resin Screw Adapter



Internal Locking Assembly of base – Note notches

Incorrect Installation



- Note, side tabs of the “Screw Adapter” are raised and “Top Hat” does not sit flush with top of the Resin Screw Adapter

Correct Installation

- 1) When screwing in the Resin Screw Adapter you should hear a “clicking” sound as the side tabs go in and out of the notches. You should stop in a position between the “clicks”.
- 2) If the “Top Hat” assembly does not sit flush with the top of the Resin Screw Adapter, untighten the Resin Screw Adapter slightly and retry.
- 3) The “Top Hat” should sit flush with only a small amount of force



- Note, side tabs of the “Screw Adapter” are almost flush with the internal ring of the adapter and “Top Hat” sits flush with top of the Resin Screw Adapter
- Please ensure correct fitment of “Top Hat” assembly prior to installation of umbrella.