

AKZ CANTILEVER UMBRELLA



Important Safety Information

This umbrella is not a permanent shade structure and must be lowered when unattended or in windy conditions. Excessive wind puts stress on the frame, which can cause damage to the umbrella and danger to people. This umbrella is not recommended for exposed environments such as high balconies or roof tops. Do not install on sloping or soft ground. Please carefully read the following instructions; if in doubt, consult a qualified trades-person. Only use recommended Shelta bases or anchoring systems.

To ensure a long life for your AKZ Cantilever umbrella:

- Close the umbrella and cover with the Protective Sleeve between uses.
- Store in a dry, shaded location if not used for long periods.
- The umbrella should be hosed regularly with fresh water if exposed to salt spray or pollution.
- Soiling of the canopy can be minimised by simply brushing off dirt before it becomes embedded in the fabric or spot cleaning soon after stains occur. Fabrics may be treated with a fabric protector such as 'Scotchguard' for additional protection.
- Do not close or store the umbrella when wet; if it is necessary to close a wet umbrella in stormy weather, remember to open and dry the canopy as soon as weather conditions allow.
- Every 6 months spray the Rotate Bearing and base plate with WD40 or deoderised fish-oil.
- Regularly check that the base of the umbrella is properly secured.

AKZ ComponentsAfter unpacking the carton, please make sure that you have the following parts:

COMPONENT	REF	QTY	
SanRemo Side-post and Umbrella	A	1	
Protective Sleeve	В	1	
Rotate Bearing (attached to side- post)	С	1	
Onground Plate Set	D	1	
Handle, screws and spanner set	E	1	0000





Fig 2 Fig 1

AKZ Mounting Options

Mounting Option 1: Onground Plate Set (D included).

Suitable for a concrete slab (minimum 10cm thick) or a concrete column (30cm diameter by 75cm deep). With this option the umbrella can be rotated. Purchase 4 Stainless Steel masonry anchors such as 10mm x 75mm Dynabolts from your local hardware.


- 1. Place the Onground Plate (E) in the required location. Use metal spacers if the surface is not flat and horizontal. Mark the position of the 4 corner holes with a felt pen. Use a 10mm masonry bit to drill holes to a depth of 80mm. Fasten the Plate to the slab using the 4 masonry anchors.
- 2. If necessary, remove the Rotate Bearing (D) from the bottom of the Sidepost and attach to the Onground plate using the four M8 x 20mm bolts and washers provided



Mounting Option 2: Shelta Resin Base (not included).

Suitable for most surfaces including timber decks. Must be ballasted with between 100 and 130 kilos of 5mm blue metal mixed with sand. Purchase a Shelta Large Resin base from your local retailer (wheeled and non-wheeled versions available). Note: the Onground Plate set is not required for this option.

- 1. Detach the Rotate Bearing (C) from the end of the side-post by removing the 2 securing screws.
- Attach the Rotate Bearing to the Resin Base "Top Hat" using the 4 countersunk screws.
- 3. Follow the assembly instructions included with the Large Resin Base.



Installing and operating the AKZ Umbrella


The AKZ umbrella frame is heavy and is best handled by 2 people; take care not to soil or damage the canopy by contacting nearby structures.


- 1. Carefully lift the umbrella and side-post to the vertical position. Hold the umbrella so that the bottom of the side-post is above the rotate bearing and carefully lower onto the rotate stem. See Figure 1 on opposite page.
- 2. Insert two M8x20mm screws with washers into the bottom of the side-post and tighten with the large Allan key.
- 3. Before opening the umbrella, release the canvas band and allow the umbrella to unfurl.
- 4. Place the crank handle onto the winder axle (about 60cm from the bottom of the side-post) and tighten the handle locking screw with the small Allan key.
- 5. Slowly turn the crank handle in a clockwise direction; if the canopy does not begin to open, check that the umbrella ribs are not tangled. DO NOT FORCE THE CRANK HANDLE.
- Turning the crank handle raises the side-post runner and simultaneously opens the canopy.
- 7. Continue to wind the crank handle until the umbrella is fully open but do not apply excessive force. See Figure 2 on opposite page.
- 8. **Tilting.** To change the angle of the umbrella canopy, pull the tilt arm away from the side-post so that the gears at the top of the tilt arm disengage from the location pin; move the tilt arm to the preferred left or right angle and re-engage the location pin; turn the tilt arm and the canopy so that the tilt arm returns to the vertical position; push the tilt arm towards the side-post so that it clicks into the side-post slot. Please note that the umbrella catches more wind when tilted and so the tilt feature should be used with extreme caution.
- Rotating. The umbrella will rotate 360 degrees by simply stepping on the rotate pedal and turning the frame by hand.
- 10. Before closing the umbrella, return the canopy to the horizontal position using the tilt arm feature. Close the umbrella by turning the crank handle anti-clockwise until the umbrella is fully closed. Secure the canopy by wrapping the canvas band around the umbrella and side-post.
- 11. Cover the closed umbrella and side-post with the Protective Sleeve (B).


Additional Instructions

- 1. **Optional LED light.** The central runner features a drop-down spigot to which the Shelta 'Flying Saucer' LED light may be attached.
- 2. **Protective Sleeve.** When not in use, tie the fabric band around the umbrella and side-post, then slip the unzipped Protective Sleeve over the top of the umbrella.
- 3. **Safety.** Never leave the umbrella unattended while open. Weather conditions can change without warning and strong gusts of wind may cause the umbrella to fall over or to break away from the mounting.
- 4. **Sun Protection.** The fabric on this umbrella is rated at UPF50+ and provides excellent protection. However on high UV days there can be significant reflected sunlight from sources such as windows and water for which Shelta recommends the use of protective clothing and sunscreen.









Attaching Shelta 'flying saucer" light

Warranty

Shelta warrants the frame of this product against manufacturer's faults for a period of 2 years from the date of purchase. Shelta repairs or replaces at our option.

Warranty does not cover:

- Damage caused by inadequate installation or inappropriate use
- Wind or other accidental damage
- Damage to fabric cover
- Normal wear and tear
- Commercial use
- Transport costs

Leaving the umbrella open in windy conditions voids the warranty.

Additional Information about this Warranty

In all cases the Shelta Warranty excludes normal wear and tear, wind damage, commercial use, use of unreasonable force, failure of reasonable care, failure of maintenance (as set out in detail below for each product), and incorrect assembly by the customer. The Shelta Warranty applies only to the original purchaser from the purchase date, and only covers (subject to the terms set out below) manufacturing faults or defects which occur in normal domestic use. Where a claim is made pursuant to the Shelta Warranty Shelta Australia will, at their discretion repair, refinish, replace, replace with a similar product or refund the product. Only the failed item will be replaced, not a complete setting. The Shelta Warranty period is not extended in the event of a replacement. In the event of a refund, it will be for wholesale price only. The balance of the retail price will be the responsibility of the retailer. In the event of a Shelta Warranty claim, please return the item to the store where purchased, with the original tax invoice. If the retailer cannot accept return of the product, please return to Shelta Australia at the address below. For residents outside Sydney, phone Shelta at the number below. Where the item is returned to Shelta Australia the purchaser must include the original tax invoice. The purchaser must also bear all costs associated with shipping the product to Shelta Australia and the return freight. The purchaser must also provide details of the problem with the product (such details must be sufficient for Shelta Australia to determine whether the Shelta Warranty applies).

Consumer Guarantees

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Such guarantees may include the right to a remedy from Shelta Australia if our products are not of an acceptable quality or do not match any demonstration model or sample (as those terms are defined in the Competition and Consumer Act 2010 (Cth) (CCA). Shelta Australia will not be liable for any act, default, omission or representation made by any person other than our employees, alterations made to the product not performed by us, damage or defects due to unusual or non-recommended use, or damage or loss caused by any factors beyond our control.

Shelta Australia's total liability in respect of a claim by a consumer under the CCA for a minor problem (as defined in the CCA) with a product is limited, at our option to, providing the consumer with a refund, replacement product or repairing the product. Subject to the above paragraphs, all express or implied representations, conditions, statutory guarantees, warranties and provisions (whether based on statute, common law or otherwise), relating to this warranty, that are not contained in it, are excluded to the fullest extent permitted by law.

Nothing in this warranty excludes, restricts or modifies any condition, warranty, statutory guarantee, right or remedy, implied or imposed by common law, statute or regulation, which cannot be lawfully excluded, restricted or modified.

Shelta Australia ©2014 ABN 95 080 881 699 4/1 Foundation Place, Pemulwuy NSW 2145 AUSTRALIA PO Box 6540, Blacktown BC, NSW 2148 AUSTRALIA Phone 61 2 8863 0400 Fax 61 2 9636 4719 www.shelta.com.au

